

If you have a Freezing issue when client running  
Please turnoff your BLUETOOTH function  
After client connected to PU AUTOPILOT, you can turn on the BLUETOOTH.