PU AIR KOREA
FORCE EXPERIENCE

It’s not big but big enough!

Click the image to watch how to setup

Copy to your community folder



Run setup file

Connection between your system and PFX.
They will be connected automatically

Connection between MSFS and PFX.
They will be connected automatically

Select Airplane to activate functions

TestMode
Test your modules



Control the output power for each functions

Control the output power for all of functions

Statements for the PFX system and output values

Control the output power for each modules